



VideoXpert v 3.7
BriefCam Integration
Installation and Operations Manual



VideoXpert[™]

Document number: C6662M-A

Publication date: 03/20

Table of Contents

Introduction 3

System Overview 3

Installing the Software 3

 Intstalling the BriefCam Plugin 3

 Installing the BriefCam Middleware 4

Using the Software 5

 Using the BriefCam Plugin 5

 Using the BriefCam Middleware 5

Troubleshooting 8

 Pelco Troubleshooting Contact Information 8

Version Information 9

 Integration Component Version 9

 BriefCam Version 9

Introduction

This document is the installation and operation manual for VideoXpert Integration with BriefCam.

System Overview


The BriefCam plugin provides seamless integration of the BriefCam web application directly into VxOpsCenter, providing an enhanced level of efficiency during an investigation.

The BriefCam middleware by Pelco enables the BriefCam server to communicate with VideoXpert and export the necessary video to create a Synopsis.


Installing the Software

Intstalling the BriefCam Plugin

1. Download and run the installer.
2. Click **Next** a few times to complete the installation process.




3. Open VxOpsCenter to verify that the new plugin is visible.




Installing the BriefCam Middleware

1. Install the prerequisite, "Microsoft Visual C++ Redistributable for Visual Studio 2015 x64".
2. Download and run the installer.
3. Click **Next** a few times to complete the installation.




4. Run the BriefCam Middleware by Pelco application to ensure successful installation.



Using the Software

Using the BriefCam Plugin

1. Drag the content plugin into an empty VxOpsCenter cell.
2. In the settings screen:


A screenshot of the 'BriefCam Settings' dialog box. It has a dark gray background with a title bar at the top containing the text 'BriefCam Settings' and a close button (X). Below the title bar, there are three text input fields labeled 'Web Host', 'Username', and 'Password'. At the bottom of the dialog, there are two buttons: 'Reset' and 'Save and Close'.

- a. Enter the *Web Host* (as an IP address) of the BriefCam server.
- b. Enter *Username* and *Password* for the BriefCam server.
- c. Click **Save and Close**.

After you save the settings, the BriefCam web application will fill the VxOpsCenter cell and be ready for use.

Using the BriefCam Middleware

1. Run the BriefCam Middleware by Pelco application.
2. Enter the *VideoXpert Host* (IP / hostname of the VideoXpert system) as well as the *VideoXpert Port*.

A screenshot of the 'BriefCam Middleware by Pelco' dialog box. It has a dark gray background with a title bar at the top containing the text 'BriefCam Middleware by Pelco' and a close button (X). Below the title bar, there are three text input fields labeled 'VideoXpert Host', 'VideoXpert Port', and 'Web Server Port'. The 'VideoXpert Port' field contains the value '443' and the 'Web Server Port' field contains the value '8080'. At the bottom right of the dialog, there is a button labeled 'Save and Close'.


3. (Optional) Change the *Web Server Port*. This is the port on the local machine that will be the web server port for this middleware. The default is 8080 although in some cases 8080 is already in use; if so, the user could change the port to 8083 for example.


VideoXpert v 3.7 BriefCam Integration Installation and Operations Manual


4. Test that the configuration is set up appropriately by navigating to “http://127.0.0.1:8080/cameras/” with a web browser. The browser should query the user for credentials; the credentials being asked for are for VideoXpert. So for example if a user “admin” exists on VideoXpert with the password “admin123” then the user would want to use those credentials in the web browser prompt.
5. (Optional) Pelco recommends that you turn off transcoding by the middleware.




Transcoding makes the import of video into BriefCam take longer, although it is necessary when the BriefCam decoder is set to Cuvid (default) and other edge cases.


 - a. Stop the Windows service “BriefCam Middleware Service” on the middleware machine.
 - b. Edit “C:\Program Files\Pelco\Integrations\BriefCam\Server\BriefCamService.exe.config” and change the “Transcode” setting from “True” to “False”.
 - c. Start the “BriefCam Middleware Service” Windows service.
 - d. Edit “C:\Program Files\BriefCam\BriefCam Server\ProcessingServer.ini” on the BriefCam server.
 - e. Remove the semicolon from the beginning of “HwAcceleratedDecoder” to enable the configuration.
 - f. Set the value for HwAcceleratedDecoder to “Cuda” from the default (Cuvid).
 - g. Reboot all BriefCam services via BriefCam Admin.
6. In the BriefCam Admin application, setup the connection to VideoXpert by adding a new directory. The “Generic HTTP integration” combo box list item will only appear if you have installed that piece of software provided by BriefCam.



7. Enter the “Address” for the URL of the Pelco middleware, for example, “http://middleware-pc:8080”.
8. Enter the *User name* and *Password* of the VideoXpert user.
9. After the directory is added, test it by pressing the  button on BriefCam Admin.



Directory name	Address		Disable
Integrations Lab	http://10.221.77.16	  	<input type="checkbox"/>

10. Add VideoXpert cameras to the BriefCam system (license them) by clicking the  button.

11. Add cameras to BriefCam by selecting the cameras from the list.

Integrations Lab - Add/Edit cameras

Licenses: 100 Remaining: 97 Activated: 3

Enter camera or directory name

Camera name	VR	<input type="checkbox"/> Active	<input type="checkbox"/> Disable	External ID	Internal ID
IP Camera - D5220-ADTQQS0	✓	<input checked="" type="checkbox"/>	<input type="checkbox"/>	25	3
IP Camera - D6220 - H050257 - 1	✓	<input checked="" type="checkbox"/>	<input type="checkbox"/>	19	2
IP Camera - D6230 - H080335 - 1	✓	<input checked="" type="checkbox"/>	<input type="checkbox"/>	12	1
Chris Desk-IMP519-1ER	✓	<input type="checkbox"/>	<input type="checkbox"/>	21	0
IMM12018-BASE-G250003 - Video	✓	<input type="checkbox"/>	<input type="checkbox"/>	15	0


12. After the directory and cameras are added, reboot the BriefCam server.
13. Lengthen the fetching timeout.
 - a. Login to the administrator web application and navigate into the environment settings at <http://briefcam-pc/admin/#/settings/environment-settings>.
 - b. Modify *the Fetching.TimeoutInSeconds* to something longer than two minutes. Positive results have been seen when set to 3600 (1hr), although exporting from VideoXpert will generally not take 1 hour.

ENVIRONMENT SETTINGS

Fetching.Timeout X Type ☐ Show settings that have been changed


Scope	Type	Key	Value	Default Value	Description
G...	Fetching ...	Fetching.TimeoutInSeconds	3600	120	

14. After the settings are saved, stop all BriefCam services via BriefCam Admin, and then restart them.
15. Login to the user web application and create a test case.
 - a. Open the web browser to <http://briefcam-pc/synopsis/#/review/cases>.
 - b. Create a new case with any title, for example "Test Case".
 - c. Click **Add Video** to export video from VideoXpert and import it into BriefCam.



- d. Select a previously licenced camera.

- e. Select a time-range to import into BriefCam and export from VideoXpert.
- f. Click **Submit** to start the video import and the creation of a Synopsis clip.



16. (Optional) Remove the "Test Case".

Troubleshooting

- Logs are located at "C:\ProgramData\Pelco\Logs\BriefCam".
- To enable verbose logging:
 1. Edit C:\ProgramData\Pelco\OpsCenter\Plugins\Pelco\BriefCam\NLog.config.
 2. Edit C:\Program Files\Pelco\Integrations\BriefCam\Client\NLog.config.
 3. Edit C:\Program Files\Pelco\Integrations\BriefCam\Server\NLog.config.
 4. Ensure 'Debug' is set for the 'minlevel' attribute all 'logger' elements.
 5. Restart the "BriefCam Middleware by Pelco" Windows service.
- VxSdk logs are located at "C:\ProgramData\Pelco\VxSdk\Logs".
- BriefCam server logs are located at "C:\Program Files\BriefCam\BriefCam Server\logs".
- When setting up BriefCam you might be required to restart all the services from their admin app, or reboot the box to have it work correctly. When things do not seem to work when they should, reboot BriefCam server.
- If the BriefCam server times out when processing video from VideoXpert, revisit Step 13 ([Lengthen the fetching timeout.](#)) of the section titled [Using the BriefCam Middleware](#).

Pelco Troubleshooting Contact Information

If the instructions provided fail to solve your problem, contact Pelco Product Support at 1-800-289-9100 (USA and Canada) or +1-559-292-1981 (international) for assistance.

Version Information

Integration Component Version

#	Component Name	Version	Description
1.	BriefCamPlugin	1.1.3.0 (Software) / 3.7.1 (VX)	The VxOpsCenter plugin for BriefCam allows the BriefCam web application to display seamlessly in VxOpsCenter.
2.	BriefCamMiddleware	1.1.3.0 (Software) / 3.7.1 (VX)	The middleware allows the BriefCam server to connect to VideoXpert providing BriefCam the ability to pull video and create a Synopsis.

BriefCam Version

#	Component Name	Version	Description
1.	BriefCam Server	5.4.1 UP2	The core server software from BriefCam.



Pelco, Inc.
625 W. Alluvial, Fresno, California 93711 United States
(800) 289-9100 Tel
(800) 289-9150 Fax
+1 (559) 292-1981 International Tel
+1 (559) 348-1120 International Fax
www.pelco.com

Pelco, the Pelco logo, and other trademarks associated with Pelco products referred to in this publication are trademarks of Pelco, Inc. or its affiliates. ONVIF and the ONVIF logo are trademarks of ONVIF Inc. All other product names and services are the property of their respective companies. Product specifications and availability are subject to change without notice.

© Copyright 2020, Pelco, Inc. All rights reserved.